

PRODUCT

PASSAGES COLLECTION
TORCHE LANTERN
PRODUCT GUIDE

DESCRIPTION


TORCHE IS A PORTABLE, RECHARGEABLE LED LANTERN WITH A SOLID OPTIC CRYSTAL, A TOUCH DIMMER, AND THREE BRIGHTNESS LEVELS.

MATERIALS


ALUMINUM
SOLID OPTIC CRYSTAL

NOTES

- THIS GUIDE COVERS TORCHE SMALL, MEDIUM, AND TALL.
- TORCHE HAS AN INTEGRATED LED AND A BUILT-IN RECHARGEABLE LITHIUM-ION BATTERY. NEITHER IS USER-REPLACEABLE.
- CHARGES WITH THE INCLUDED USB-C CABLE AND WALL ADAPTER. A FULL CHARGE TAKES ABOUT 4 HOURS.
- FOR INDOOR USE IN DRY LOCATIONS ONLY.
- NEVER PICK UP OR HOLD TORCHE BY THE CRYSTAL.
- READ ALL SAFETY INFORMATION ON THE BACK OF THIS GUIDE BEFORE FIRST USE, AND KEEP THIS GUIDE FOR FUTURE REFERENCE.




AMERICAN DESIGN
BY LAKE  WELLS
CHICAGO



CHARGING

- Fully charge Torche before first use.
- Plug the USB-C cable into the port on the base and into the included wall adapter, then plug the adapter directly into a wall outlet.
- A full charge takes about 4 hours. Unplug Torche once it is charged.
- Torche can be used while it is charging.
- Use only the included cable and adapter, or a certified 5V USB-C replacement.



OPERATION

- Pinch the dimmer ring to turn Torche on.
- Pinch again to step through three brightness levels. The next pinch turns the light off.

CRYSTAL CARE

- The crystal is set with a flexible adhesive, so slight movement between the crystal and the lamp is normal. This is intentional and protects the crystal.
- Never pick up, hold, or carry Torche by the crystal. Lake + Wells is not responsible for crystals that detach due to improper handling.
- Damaged crystals can be replaced. Contact us for a quote.

SAFETY AND CARE

Torche contains a lithium-ion battery. Improper charging, handling, or disposal can cause overheating, fire, or injury. Please read and follow these precautions.

CHARGING

- Do not leave Torche charging unattended or overnight.
- Charge on a hard, flat surface. Never charge on beds, sofas, carpet, or near curtains, paper, or other flammable materials.
- Charge indoors at room temperature, in a dry, ventilated space. Do not cover Torche or the adapter while charging.
- Let Torche cool to room temperature before charging.
- Plug the adapter directly into a wall outlet. Avoid extension cords and power strips.
- Do not use a damaged cable or adapter.

USE

- For indoor use in dry locations only. Do not submerge or expose to water.
- Keep away from open flames, heaters, and fireplaces. Do not leave in direct sunlight or a hot car.
- Do not drop, crush, or puncture. After a hard impact, stop using Torche and contact us.
- Torche is not a toy. Keep out of reach of small children and pets.

STOP USING IMMEDIATELY IF YOU NOTICE

- Excessive heat, swelling, or a warped housing
- A burning smell, smoke, hissing, or leaking fluid
- Torche no longer holds a charge

Unplug Torche if it is safe to do so, move it away from anything flammable, and contact Lake + Wells. If it smokes or catches fire, leave the area and call 911.

STORAGE

- For long-term storage, charge to about half and keep in a cool, dry place. Recharge every 3 months. Do not store in a hot garage, attic, or vehicle.

SERVICE AND DISPOSAL

- The battery and LED are sealed. Do not open, modify, or repair Torche. Doing so voids the warranty and may create a fire hazard.
- Do not place Torche in household trash or recycling. Take it to a battery recycling drop-off or household hazardous waste site (call2recycle.org).

CLEANING

- Wipe the aluminum with a soft, dry cotton cloth. Clean the crystal with a soft cloth lightly dampened with glass cleaner (no additives). Never spray the lamp directly, and keep liquids away from the charging port.